

力器系统余工艺

n

深圳市华成工业控制股份有限公司

Shenzhen HuS

前言

R6

-
(),
,
,
,
-
-

R6 -

A0	2020-11	

1		1
1.1		1
1.2		1
1.3		1
1.4		1
1.5		2
2		3
2.1		3
2.2		3
3		4
3.1		4
3.2		6
3.2.1		6
3.2.2		7
3.2.3		7
3.2.4		8
3.2.5		8
3.2.6		9
4		9
4.1		9
4.2		10

1

2

3

:

1)

2)

3)

4)

5)

6)

1)

2)

3)

4)

5)

6)

7)


50

8)

1. 2.0.2.1, 7.8.01 ()
2. -> -> ()
3. , -> RS485 ,
-> RS485 [2.2](#) ()
4. , -> RS485 RS485
, -> RS485 [2.2](#)
()
5. , 7,8 , 7,8 ()

CAN/

:



CAN/

->

,

->

插入

模式选择 直线

请获取模块信息

获取模块信息

保存到模块

设入

试运行P1

速度: 10.0

%

平滑度

无

P1

P2

设入

试运行P2

速度: 10.0

%

模拟量设定

通道0: 5.0

输出点设定

Y10

动作

菜单

短谷返回

1.

2.

3. Pn

4. Pn Pn

5. Pn

1 P1

2 Pn [3.2](#)

6.

7.

模拟量通道	值	添加	确定
通道 0	0	删除	取消

8.

输出点 延时(s) 添加 确定

输出点	延时(s)
Y 10.~	0.~

取消

9.

10.

请选择插入的模块

☐ 插入到现有模块

☒ 新建模块

请新建一个模块

模块名称: 直线

确定 取消



2

3

11.

,

插入	调用模块	
	返回标签	
	动作	
	菜单	

12.


:

->



1. P1 P1->P2 P2 P2->P1 P1
2. P1-P2 P1-P2 P2-P1

3.2.2



1. P1 P1->P3 P3 P3->P1 P1
2. P1-P2-P3 P1-P2-P3 P3-P2-P1

3.2.3



1. P1 P1->P2 P2 P2->P1 P1 P3

2. n

3.2.4

插入	模式选择 曲面	请获取模块信息	获取模块信息	保存到模块
	设入	试行P1	速度: 10.0 %	平滑度 3 模拟量设定 通道0:2.0 通道1:3.0 输出点设定 Y10 Y12 Y14
	设入	试行P2	速度: 10.0 %	
	设入	试行P3	速度: 10.0 %	
	设入	试行P4	速度: 10.0 %	
动作菜单	n次数: 0 次			

1. P1 P1->P3 P3 P3->P1 P1 P2 P4

2. n

3.2.5

插入	模式选择 平面寸动	请获取模块信息	获取模块信息	保存到模块
	设入	试行P1	速度: 10.0 %	平滑度 无 模拟量设定 通道0:5.0 输出点设定 Y10
	设入	试行P2	速度: 10.0 %	
	设入	试行P3	速度: 10.0 %	
动作菜单	n次数: 3 次 往返次数: 3 次 寸动开枪 寸动速度: 10.0 %			

1. P1 P1->P2 P2 P2->P1 P1 P3

2. n

3. 0 1
- 4.
- 5.

3.2.6



1. P1 P1->P3 P3 P3->P1 P1 P2 P4
2. n
3. 0 1
- 4.
- 5.

```
0:      :      :0      :0      :0|5.00      :rev      :9      :3

P1:759.704|103.042|1359.972|-62.272|21.089|-32.330 P1      :10.0
P2:760.023|100.661|1359.972|-62.272|21.089|-32.509 P2      :20.0
P3:761.561|100.656|1354.616|-62.504|21.430|-32.593 P3      :30.0
P4:514.000|0.000|865.000|0.000|90.000|0.000 P4      :10.0

:2 P1      :0 P2      :0 P3      :0 P4      :1
```

P1J:0.000|0.000|12.932|-66.558|45.860|16.566 P2J:-0.179|0.000|12.932|-66.558|45.860|16.566

P3J:-0.179|0.000|12.528|-66.558|45.860|16.566 P4J:0.000|0.000|0.000|0.000|0.000|0.000

IO:5|0.0 :1 :10.0 :0

1: : :J1:0.000,J2:0.000,J3:12.932,J4:-66.558,J5:45.860,J6:16.566

:10 :0.00 :

2: -0: :5.00 :0.0

3: :Y015 :0.0

4: : :X:760.023,Y:100.661,Z:1359.972,U:-62.272,V:21.089,W:-32.509

:20 :0.00 :9

5: : :X:760.217,Y:103.040,Z:1358.187,U:-62.272,V:21.089,W:-32.330

:10 :0.00 :9

6: : :X:760.536,Y:100.659,Z:1358.187,U:-62.272,V:21.089,W:-32.509

:20 :0.00 :9

7: : :X:760.729,Y:103.039,Z:1356.401,U:-62.272,V:21.089,W:-32.330

:10 :0.00 :9

8: : :X:761.048,Y:100.658,Z:1356.401,U:-62.272,V:21.089,W:-32.509

:20 :0.00 :9

9: : :X:761.242,Y:103.037,Z:1354.616,U:-62.272,V:21.089,W:-32.330

:10 :0.00 :9

10: : :X:761.561,Y:100.656,Z:1354.616,U:-62.272,V:21.089,W:-32.509

:20 :0.00 :

11: :Y015 :0.0

12:

1.

2. 8

[3.2](#) P1

3.

4.

2

1

5.

:

0: : :J1:0,J2:0,J3:0,J4:0,J5:-90.000,J6:0

:80.0 :0.00 :

1: :[ID1]

2: : : +

:0 :200.000 :0.000 :20.0

3: [2]:

4: : : +

5: :[ID0]

6:

[2]:

0: : :0 :0 :0|1.00 :rev :9 :3

P1:759.704|103.042|1359.972|-62.272|21.089|-32.330 P1 :10.0

P2:760.023|100.661|1359.972|-62.272|21.089|-32.509 P2 :20.0

P3:761.561|100.656|1354.616|-62.504|21.430|-32.593 P3 :30.0

P4:514.000|0.000|865.000|0.000|90.000|0.000 P4 :10.0

:2 P1 :0 P2 :0 P3 :0 P4 :1

P1J:0.000|0.000|12.932|-66.558|45.860|16.566 P2J:-0.179|0.000|12.932|-66.558|45.860|16.566

P3J:-0.179|0.000|12.528|-66.558|45.860|16.566 P4J:0.000|0.000|0.000|0.000|0.000|0.000

IO:5|0.0 :1 :10.0 :0

1: : :J1:0.000,J2:0.000,J3:12.932,J4:-66.558,J5:45.860,J6:16.566

:10 :0.00 :

2: -0: :1.00 :0.0

3: :Y015 :0.0

4: : :X:760.023,Y:100.661,Z:1359.972,U:-62.272,V:21.089,W:-32.509

:20 :0.00 :9

5: : :X:760.217,Y:103.040,Z:1358.187,U:-62.272,V:21.089,W:-32.330

:10 :0.00 :9

6: : :X:760.536,Y:100.659,Z:1358.187,U:-62.272,V:21.089,W:-32.509

:20 :0.00 :9

7: : :X:760.729,Y:103.039,Z:1356.401,U:-62.272,V:21.089,W:-32.330

:10 :0.00 :9

8: : :X:761.048,Y:100.658,Z:1356.401,U:-62.272,V:21.089,W:-32.509

:20 :0.00 :9

9: : :X:761.242,Y:103.037,Z:1354.616,U:-62.272,V:21.089,W:-32.330

:10 :0.00 :9

10: : :X:761.561,Y:100.656,Z:1354.616,U:-62.272,V:21.089,W:-32.509

:20 :0.00 :

11: :Y015 :0.0

12:

8:

0: :X014

1: : : +

X:756.221,Y:94.684,Z:1356.886

2: :1.0s

3:

8



518000

0755-26417678

0755-26416578

